



SPRING SHOW 2D ARTWORK WILL BE HUNG BY WAA STAFF ON ONE OR TWO "PIN HOOKS" (DEPENDING ON THE SIZE AND WEIGHT OF THE PIECE) ON WAA'S CARPET COVERED PANELS. PICTURE HANGING WIRES MUST BE SLACK ENOUGH FOR A PERSON TO REACH BEHIND THE ARTWORK AND PLACE THE WIRE CAREFULLY ONTO THE TINY HOOKS. BE SURE THAT THE HANGING WIRE DOES NOT ALLOW YOUR PICTURE TO LEAN OUTWARD, NOR SHOULD THE WIRE BE VISIBLE WHEN THE PICTURE IS HUNG.

TO PREVENT YOUR ARTWORK FROM LEANING OUTWARD, ATTACH YOUR D-RINGS OR SCREW EYES ABOUT 1/4th OF THE WAY DOWN FROM THE TOP OF THE FRAME. WE HAVE ENCOUNTERED HANGING WIRES THAT SLIP WHEN SUPPORTING THE WEIGHT OF THE PICTURE, A SITUATION THAT COULD CAUSE A PICTURE TO FALL OFF THE PANEL. WE SUGGEST THE FOLLOWING METHOD OF ATTACHING A WIRE SECURELY TO THE HARDWARE SCREWED INTO THE BACK OF YOUR FRAME:

LAY THE WIRE ACROSS THE BACK, THROUGH THE D-RINGS OR SCREW EYES LEAVING ABOUT SIX INCHES OF EXTRA WIRE ON EACH SIDE. HOLD THE LEFT END OF THE WIRE AND BEND IT AROUND THE HANGING WIRE, THEN PASS THE END OF THE WIRE ONCE AGAIN THROUGH THE LOOP. NEXT TWIST THE END WIRE AROUND THE HANGING WIRE IN SIX OR MORE TIGHT TWISTS. ALLOW ABOUT TWO INCHES OF SLACK IN THE WIRE AND THEN ATTACH THE RIGHT END OF THE WIRE TO THE D-RING OR EYE LOOP IN THE SAME WAY.

THESE ARE GENERAL GUIDELINES AND THEY SHOULD BE ADJUSTED TO SUIT THE SIZE OF YOUR OWN WORK. MAKE SURE THE WIRE IS OF ADEQUATE SIZE TO SUPPORT THE PAINTING.

WAA SPRING SHOW HANGING GUIDELINES - VIEW FROM BACK